


NOTES:

1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
2. DO NOT SCALE DRAWINGS.
3. THE TOTAL COMBINED HEIGHT OF BIGFOOT SYSTEMS FOOTING FORM MUST NOT EXCEED THIRTEEN FEET (13')
4. SCREW CONSTRUCTION TUBE TO FOOTING FORM WITH A MINIMUM OF FOUR 3/4" WOOD SCREWS.
5. BIGFOOT SYSTEMS FOOTING FORMS MUST BE PLACED ON UNDISTURBED GROUND OR 4"-6" COMPACTED GRAVEL.
6. CHECK ALIGNMENT OF CONSTRUCTION TUBE BEFORE BACKFILLING.
7. BACK FILL MUST BE PLACED UP TO LIFT 1. APPROXIMATELY 16" OF BACKFILL FROM THE BOTTOM OF THE FOOTING FORM. BACKFIELD SHOULD BE CONSOLIDATED WITH A MANUAL PLATE TAMPER OR A 2X4 ON END. DO NOT STRIKE BIGFOOT SYSTEMS FOOTING FORM. DO NOT OVERCONSOLIDATE AS TO DISTORT THE SHELL OF THE FOOTING FORM
8. COMPLETE BACKFILL OF BELOW GRADE PIERS UP TO A MAXIMUM HEIGHT OF FIVE FEET. EACH LIFT SHOULD BE CONSOLIDATED WITH A MANUAL PLATE TAMPER OR A 2X4 ON END.
9. CONTRACTORS NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT www.CADdetails.com/info REFERENCE NUMBER 552-003.



BIGFOOT SYSTEMS® FOOTING FORM

BELOW GRADE OPERATION